Manual

DIAZ | SUNPROTECTION

Installation of the inversed pleat

1. Take the first hook (far left or right) and hook it into the rail backwards (from back to front). This ensures that the curtain closes nicely at the side and the pleat falls correctly.

2. All the hooks in between are hooked in the same way, from front to back. Continue hook by hook along the rail.

3. The last hook is hooked in reverse again (from back to front).





